

We Asked. **You Answered.** We Delivered.

KIMTECH PURE* A5 Cleanroom Apparel



Choose the Coverall That's Right for You

We know you're always looking for ways to safeguard employees and save money. So with help from users like you, we developed leading-edge KIMTECH PURE[®] A5 Cleanroom Apparel, with two coverall options.

Both offer the engineered performance you count on from KIMBERLY-CLARK PROFESSIONAL[®]. Both deliver KIMTECH PURE[®] Brand peace of mind – quality, protection and value to advance your process outcomes. Both come with the supply chain support and product expertise you deserve.

We Asked. **You Answered.** We Delivered.

We designed our new KIMTECH PURE[®] A5 Sterile Cleanroom Apparel based on input from industry professionals like you. Then we asked cleanroom professionals to rate its problem-solving features. Here's what they said:

100% of cleanroom operators surveyed agreed that exclusive arm and leg snaps will help prevent contamination during gowning.[†]

93% of cleanroom operators surveyed preferred this fold design to protect against contamination during the gowning procedure.[†]

86% of cleanroom operators felt the blue line lowers the risk of contamination by facilitating aseptic gowning.[†]



Mandarin Collar comes up higher on the neck for added protection.

FEATURED ON CLEAN PROCESSED COVERALLS

Engineered Performance for Every Situation

What makes KIMTECH PURE[®] A5 the coverall of choice for both sterile and clean environments? KIMTECH PURE[®] A5 Coveralls deliver the reliable protection you're required to provide, and the peace of mind your team deserves. Both sterile and clean processed options offer an ideal balance of comfort, protection and efficiency. The garments are KIMBERLY-CLARK PROFESSIONAL[®] engineered to open easily, stay in place and reduce the chance of contamination.

KIMTECH PURE[®] A5 Coverall – Clean Processed

The KIMTECH PURE[®] A5 coverall effectively combines quality and value. Users will appreciate the comfort and ease of donning. Choosers will appreciate the value and long-term cost savings. Discover features and benefits like these:

- High-quality, affordable solution for many cleanroom needs
- Patented REFLEX[®] Design is 7.5 times more rip-resistant than ANSI minimums
- Mandarin collar, comes up higher on the neck for added protection

Built-In Thumb Loop keeps garment sleeve from rolling back and exposing arm or wrist.

FEATURED ON ALL COVERALLS

Cloth-Like Comfort is delivered by the SMS (Spunbond Meltblown Spunbond) material that goes into every KIMTECH PURE[®] A5 Coverall.

FEATURED ON ALL COVERALLS

High-Quality, Affordable

Clean processed coveralls deliver comfort, value and long-term cost savings.

FEATURED ON CLEAN PROCESSED COVERALLS



**Shown: KIMTECH PURE[®] A5
Cleanroom Coverall - Sterile**

Patent-Pending Highly Visible Blue Line
along the inside of the garment signals the proper
place to grasp while gowning, helping workers
avoid touching the outside of the garment.

FEATURED ON STERILE COVERALLS



CLEAN-DON[®] Technology for Sterile Environments

KIMTECH PURE[®] A5 Coverall - Sterile with CLEAN-DON[®] Technology

This innovative coverall meets your cleanroom needs like no other. From performance to protection, it's a real problem solver. The KIMTECH PURE[®] A5 Coverall-Sterile is engineered for comfort, with features and benefits that make it simple and safe to use.

- Ideal for demanding cleanroom jobs
- Incorporates features of standard KIMTECH PURE[®] A5 Coveralls
- Patented REFLEX[®] Design is 7.5 times more rip-resistant than ANSI minimums
- Innovative design helps reduce the risk of contamination, which ultimately reduces wasted garments in donning.

Patent-Pending Snap Technology

features built-in snaps that gather up legs and arms to lower the risk of touching the floor, then automatically release as garment is put on.

FEATURED ON STERILE COVERALLS

Innovative Inside-Out Fold

pattern presents the inside of the garment as the package is opened, reducing the risk of touching and contaminating the outside of the apparel.

FEATURED ON STERILE COVERALLS

Gowning with CLEAN-DON[®] Technology Same Procedure. Simplified.

One great thing about the new KIMTECH PURE[®] A5 Coverall - Sterile with CLEAN-DON[®] Technology is that you don't have to make changes to your gowning procedure. It simply becomes less complicated.



- Tear open the vacuum-packaged apparel
- Grasp the blue line



- Pull out the garment
- Hold it up



- Gently unfold the arms and legs

- Begin gowning
(built-in snaps release arms and legs as you put on the garment)

- Slip thumbs through thumb loop

- Zip up coverall



Technical Data and Product Information

Technically Advanced

From bound seams and tunneled elastic to lot-controlled manufacturing, KIMTECH PURE[®] A5 Cleanroom Apparel meets your high standards for cleanroom performance. Our entire design and manufacturing process has been developed to guard against contamination.

KIMTECH PURE[®] A5 Cleanroom Apparel is manufactured in an ISO certified facility, clean processed, then individually packaged under cleanroom conditions. These garments contain no natural rubber latex.

For complete technical data and certifications available on all KIMTECH[®] Brand Cleanroom Products, contact your KIMBERLY-CLARK PROFESSIONAL^{*} Representative today or visit www.kimtech.com/wedelivered.

KIMTECH PURE[®] A5 Cleanroom Apparel^{**}

| Codes | Description | Case/Pack | Weight | Case Dimensions LxWxD (inches) | Pallet Layer/Stack |
|-------|--------------------------|-----------|--------|--------------------------------|--------------------|
| 88800 | SMALL COVERALL, STERILE | 25/case | 12.25 | 19.5 x 11.75 x 14.375 | 8 x 5 = 40 |
| 88801 | MEDIUM COVERALL, STERILE | 25/case | 13.25 | 19.5 x 11.75 x 14.375 | 8 x 5 = 40 |
| 88802 | LARGE COVERALL, STERILE | 25/case | 14.25 | 19.5 x 11.75 x 14.375 | 8 x 5 = 40 |
| 88803 | XL COVERALL, STERILE | 25/case | 15.25 | 19.5 x 11.75 x 16.375 | 8 x 5 = 40 |
| 88804 | 2XL COVERALL, STERILE | 25/case | 16.50 | 19.5 x 11.75 x 16.375 | 8 x 5 = 40 |
| 88805 | 3XL COVERALL, STERILE | 25/case | 17.50 | 19.5 x 11.75 x 16.375 | 8 x 5 = 40 |
| 88806 | 4XL COVERALL, STERILE | 25/case | 18.50 | 19.5 x 11.75 x 16.375 | 8 x 5 = 40 |
| 12917 | 5XL COVERALL, STERILE | 25/case | 19.20 | 19.5 x 11.75 x 16.375 | 8 x 5 = 40 |
| 12914 | 6XL COVERALL, STERILE | 25/case | 19.40 | 19.5 x 11.75 x 18.625 | 8 x 4 = 32 |
| 88807 | HOOD, STERILE | 100/case | 13.60 | 19.5 x 11.75 x 14.375 | 8 x 5 = 40 |
| 88808 | UNIVERSAL BOOTS, STERILE | 100 pairs | 18.75 | 19.5 x 11.75 x 14.375 | 8 x 5 = 40 |
| 12922 | SM/MD BOOTS, STERILE | 100 pairs | 18.40 | 19.5 x 11.75 x 11.375 | 8 x 7 = 56 |
| 12920 | XL/2XL BOOTS, STERILE | 100 pairs | 19.20 | 19.5 x 11.75 x 11.375 | 8 x 7 = 56 |
| 88842 | SMALL COVERALL | 25/case | 12.25 | 19.5 x 11.75 x 14.375 | 8 x 5 = 40 |
| 88843 | MEDIUM COVERALL | 25/case | 13.25 | 19.5 x 11.75 x 14.375 | 8 x 5 = 40 |
| 88844 | LARGE COVERALL | 25/case | 14.25 | 19.5 x 11.75 x 14.375 | 8 x 5 = 40 |
| 88845 | XL COVERALL | 25/case | 15.25 | 19.5 x 11.75 x 16.375 | 8 x 5 = 40 |
| 88846 | 2XL COVERALL | 25/case | 16.50 | 19.5 x 11.75 x 16.375 | 8 x 5 = 40 |
| 88847 | 3XL COVERALL | 25/case | 17.50 | 19.5 x 11.75 x 16.375 | 8 x 5 = 40 |
| 88848 | 4XL COVERALL | 25/case | 18.50 | 19.5 x 11.75 x 16.375 | 8 x 5 = 40 |
| 12916 | 5XL COVERALL | 25/case | 19.50 | 19.5 x 11.75 x 16.375 | 8 x 5 = 40 |
| 12915 | 6XL COVERALL | 25/case | 19.50 | 19.5 x 11.75 x 18.625 | 8 x 4 = 32 |
| 88849 | HOOD | 100/case | 13.60 | 19.5 x 11.75 x 14.375 | 8 x 5 = 40 |
| 88850 | UNIVERSAL BOOTS | 100 pairs | 18.75 | 19.5 x 11.75 x 14.375 | 8 x 5 = 40 |
| 12921 | SM/MD BOOTS | 100 pairs | 18.40 | 19.5 x 11.75 x 11.375 | 8 x 7 = 56 |
| 12919 | XL/2XL BOOTS | 100 pairs | 19.20 | 19.5 x 11.75 x 11.375 | 8 x 7 = 56 |

^{**} Gamma Irradiated SAL:10⁶

STERILE APPAREL

CLEAN PROCESSED APPAREL



The Head-to-Toe Cleanroom Solution Designed to Work Around You

Go to: www.kimtech.com/getsamples for your free samples

KIMTECH PURE® A5 Cleanroom Apparel is just one of a full range of gloves, masks, eye protection, apparel and wipers designed for the rigorous standards of cleanroom environments. Learn more at www.kimtech.com.

Need help selecting your cleanroom apparel? Go to www.kimtech.com/virtualmodel

Certified Quality Documentation: For Certificates of Conformance and Certificates of Irradiation, visit www.kimtech.com/certificates or e-mail kimtech@kcc.com.

TECHNICAL HELP

E-MAIL: kimtech@kcc.com

1.800.851.7538

Our Guarantee

Your total satisfaction means everything to us. If, for any reason, our products do not meet your expectations, Kimberly-Clark will reimburse you† for your initial purchase, via FREE product, for up to \$1,000. For more information on KIMBERLY-CLARK PROFESSIONAL®, visit us online at www.kcprofessional.com, contact your Kimberly-Clark Sales Representative, or call us at 1-888-346-GOKC (4652).

† Guarantee extended to consuming end-user accounts only.

Reduce Today, Respect Tomorrow* is the KIMBERLY-CLARK PROFESSIONAL* approach to sustainability. It begins with the understanding that the way we use resources today shapes the world of tomorrow. And it has led us to focus on reducing consumption at every stage of the product lifecycle – from design and manufacture to distribution and disposal. Reduction is the key to lowering the environmental impact of our activities as well as those of customers. To learn more, visit www.kcreducetoday.com/us



Kimberly-Clark warrants that its products comply with K-C's standard specifications as of the delivery date to K-C's authorized distributors/direct purchasers. Except to the extent prohibited by applicable law: 1) **THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE;** 2) K-C is not liable for any kind of special, incidental, or consequential damages; and 3) K-C's liability for breach of contract, tort, or other cause of action shall not exceed the product purchase price. Purchasers and users are deemed to have accepted the above warranty and limitation of liability, and cannot change the terms by verbal agreement or by any writing not signed by K-C. To the extent required by applicable law, K-C does not limit its liability for death/injury resulting from K-C's negligence.

®/* Trademarks of Kimberly-Clark Worldwide, Inc. or its affiliates. Marques déposées de Kimberly-Clark Worldwide, Inc. ou de ses filiales. © 2010 KCWW. K02068 K4645-10-01 6/10

Effective June 2010